

ODP Business Sourcing, LLC Limited Five Year Product Warranty

This limited warranty covers the original purchase of new product used for normal commercial, personal or household use. ODP Business Sourcing, LLC (ODP Business Sourcing) warrants its products will be free from defects in materials and workmanship (normal wear and tear excepted), for five (5) years from the date of purchase, except as provided below. ODP Business Sourcing, at its option, will replace with a comparable product, free of charge, any product purchased from it that fails under normal use as a result of such defect. This warranty does not apply to damage caused by fire, accident, negligence, misuse, use other than as stated in product instructions, improper cleaning or other circumstances not directly attributable to defects in materials and workmanship.

Natural variations occurring in wood or other materials will not be considered defects, and ODP Business Sourcing does not warrant the color-fastness or matching of colors, grains, or textures of such materials. This warranty does not apply to: modifications of the product, attachments to the product not approved by ODP Business Sourcing, and products that were not installed, used, or maintained in accordance with product instructions and warnings.

This warranty has the following exceptions: Fabrics, foam, veneer finishes and other covering materials are warranted for three years from date of purchase.

Proof of purchase is required in the form of a receipt (copy or original) to validate warranty. Warranty claims without the receipt may be rejected.

If ODP Business Sourcing chooses to provide a refund for such product, it will be fulfilled in the form of an Office Depot Merchandise card. Claims fulfilled in this manner take approximately 30 days to process.

ODP BUSINESS SOURCING PROVIDES THIS LIMITED WARRANTY IN LIEU OF ALL OTHER WARRANTIES EITHER EXPRESSED OR IMPLIED. EXPRESSLY EXCLUDED ARE ALL WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE OR MERCHANTABILITY. ODP BUSINESS SOURCING'S SOLE OBLIGATION AND THE USER'S EXCLUSIVE REMEDY UNDER THIS WARRANTY SHALL BE LIMITED TO THE REPAIR, REFUND (IN THE FORM OF AN OFFICE DEPOT MERCHANDISE CARD) OR REPLACEMENT AT ODP BUSINESS SOURCING'S SOLE DISCRETION AND COST, OF PRODUCT OR COMPONENTS.

IN NO EVENT SHALL ODP BUSINESS SOURCING, ITS AFFILIATES, SUBSIDIARIES OR PARENT COMPANIES BE RESPONSIBLE FOR CONSEQUENTIAL, SPECIAL, OR INCIDENTAL DAMAGES ARISING OUT OF A CLAIM OF DEFECTIVE PRODUCT EVEN IF ODP BUSINESS SOURCING HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

SOME STATES OR PROVINCES DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES OR LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS OR THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH MAY VARY BY STATE OR PROVINCE.

THIS WARRANTY APPLIES ONLY TO THE U.S. AND CANADA.

Service Instructions

Please call: 1-800-949-9974 for warranty service.




MOUNTING INSTRUCTIONS



HANGING INSTRUCTIONS

Porcelain Board


Required Tools:




Parts List:




Insert the marker tray at a (approx.) 15° angle.




Measure the board size to determine the location, make sure the board is horizontally placed, then mark the location of bracket E.




Drill holes for each hanger in marked locations using 1/4" drill bit.




Tap the metal expansion screw (B+C) into the hole by a hammer. Then use a screw driver to turn the screw C clockwise until strong resistance is felt so the metal screw is firmly fixed on the wall.




Turn the screw C anticlockwise to remove it from B (the rest part). Then re-insert the screw C through the hanging bracket E to make sure E is fixed firmly on the wall.




Holding the board at a (approx.) 25° angle. Place the channel in the back of the frame over the wall anchors. Lower the board so it is well placed to the wall.




Draw lines along the board bottom frame, then remove the board from wall.




Mark the center position of bracket G.




Use a 1/4" drill bit to drill in marked locations.



Tap the expansion screws into the wall by a hammer and then turn the screws through the hanging brackets into the expansion screws.



Re-hang the board.



Mark the drilling positions on the side of the frame through bracket G, use 1/8" drill bit to drill holes at marked positions, then insert the screw D through bracket G into the pilot hole, fasten firmly.