

Office Depot, Inc. Limited One Year Product Warranty

This limited warranty covers the original purchase of new product used for normal commercial, personal or household use. Office Depot, Inc. (ODI) warrants its products will be free from defects in materials and workmanship (normal wear and tear excepted), for one (1) year from the date of purchase, except as provided below. ODI, at its option, will replace with a comparable product, free of charge, any product purchased from it that fails under normal use as a result of such defect. This warranty does not apply to damage caused by fire, accident, negligence, misuse, use other than as stated in product instructions, improper cleaning or other circumstances not directly attributable to defects in materials and workmanship.

Proof of purchase is required in the form of a receipt (copy or original) to validate warranty. Warranty claims without the receipt may be rejected.

If Office Depot, Inc. chooses to provide a refund for such product, it will be fulfilled in the form of an Office Depot Merchandise card. Claims fulfilled in this manner take approximately 30 days to process.

ODI PROVIDES THIS LIMITED WARRANTY IN LIEU OF ALL OTHER WARRANTIES EITHER EXPRESS OR IMPLIED. EXPRESSLY EXCLUDED ARE ALL WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE OR MERCHANTABILITY. OFFICE DEPOT'S SOLE OBLIGATION AND THE USER'S EXCLUSIVE REMEDY UNDER THIS WARRANTY SHALL BE LIMITED TO THE REPAIR, REFUND (IN THE FORM OF AN OFFICE DEPOT MERCHANDISE CARD) OR REPLACEMENT AT ODI'S SOLE DISCRETION AND COST, OF PRODUCT OR COMPONENTS.

IN NO EVENT SHALL ODI, ITS AFFILIATES, SUBSIDIARIES OR PARENT COMPANIES BE RESPONSIBLE FOR CONSEQUENTIAL, SPECIAL, OR INCIDENTAL DAMAGES ARISING OUT OF A CLAIM OF DEFECTIVE PRODUCT EVEN IF ODI HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

SOME STATES OR PROVINCES DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES OR LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS OR THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH MAY VARY BY STATE OR PROVINCE.


THIS WARRANTY APPLIES ONLY TO THE U.S. AND CANADA.

Service Instructions

Please call 1-800-949-9974 for warranty service (Mon – Fri, 8am to 8pm EST).

realspace™

Traditional Banker's Lamp



Traditional Banker's Lamp

Assembly instructions and warranty information

Lampe de banquier traditionnel

Instructions pour l'assemblage et information sur la garantie

Lámpara de banquero tradicional

Instrucciones para el ensamblaje e información sobre la garantía

For customer support, call 1-800-949-9974

Pour le support client, appelez le 1-800-949-9974

Llame para asistencia al cliente 1-800-949-9974

Date Manufactured / Date de fabrication / Fecha de manufactura: 04 /2020

Lot # / Nombre de sort / Número de lote: 0420001

versio 0420

Item 688-029

Realspace is a trademark or registered trademark of The Office Club, Inc.
© 2020 Office Depot, Inc. All Rights Reserved. Made in China

Warning

TO REDUCE THE RISK OF FIRE, ELECTRICAL SHOCK OR PERSONAL INJURY.

- Turn off/unplug and allow to cool before replacing bulb, cleaning or other maintenance.
- Lamp is for indoor use only.
- Use the unit only with the accessories delivered with the lamp.
- Avoid eye contact with bulbs: when lit.
- If the supply cord or adaptor is damaged, it must be replaced by a service agent or a similarly qualified person in order to avoid a hazard.
- Do not continue to touch the lamp or bulb if skin feels warm
- Keep lamp away from materials that may burn
- This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter the plug.

Thank you for purchasing this product. We trust that you will be completely satisfied with your product for years to come. This product is backed by a 1 year limited warranty and has been crafted with today's lifestyles in mind.

Call Us First!

DO NOT RETURN TO STORE.

For immediate help with assembly or product information call our toll-free number:

1-800-949-9974 Mon-Fri 8am-8pm EST.

Our staff is ready to provide assistance.

Damaged or missing parts ship from our facility in 1-2 business days

NOTE: When assembling the parts, make sure the wire is not pinched between the parts being assembled.

Date Purchased: _____

Customer Service: 1-800-949-9974

1. Before beginning the assembly process, carefully pull all excess cord out through the bottom of the lamp base. Continue pulling the cord until the upper section of the lamp is lined up with the bottom section and no excess cord is visible.

2. Carefully remove all pieces from the packaging. Remove the LED Bulb from its box.

3. Screw the upper part of the arm (B) into the connector on the shade (A) and rotate to tighten.


5. Screw the lower part of the arm (B) tightly into the threaded stem (C) on the lamp base and rotate to tighten.

6. Install the 10W LED Bulb (D) into the socket of the lamp holder and screw it tightly in.

7. If necessary, turn the nut (F) and tighten.

8. Plug into wall outlet

9. Turn the lamp on with the chain switch (E) conveniently located on the shade of the lamp



CARE AND MAINTENANCE:

Always ensure the product is unplugged from the electrical outlet and allowed to cool before assembling, disassembling, relocating, servicing, or cleaning it.

Clean the product with a soft cloth; do not use liquids, abrasive cleaners, or solvents.

BULB REPLACEMENT:

1. Ensure the product is unplugged and cool to the touch before proceeding.
2. Remove the 10W LED bulb from the socket.
3. Replace old bulb with new 10W LED bulb.

WARNING: Use 10W LED bulb or smaller